

Process sheet for **stf_res_01**
Physics and Hardware for Intelligence project
Physical Measurement Laboratory, NIST Boulder
Dated Thursday 27th February, 2020



Abstract

Fabrication flow for the SPD/JJ integration process. WSi SNSPDs are integrated with Nb/Si/Nb, externally shunted JJs. This process includes the superconducting thin-film layer and associated Nb wiring and Au resistors, a ground plane, the JJ tri-layer stack and associated PdAu shunt resistor layer, and an upper Nb wiring layer.

The process starts with a thermally oxidized Si wafer with 160 nm SiO₂.

The entire wafer is clad with oxide, and openings are etched to the bond pads (**v4**). A Nb ground plane is deposited, and alignment marks are etched in this layer. Features are then etched in the ground plane (**m0**).

Insert screen shot of die and image distribution from stepper:

Contents

	4	STF (superconducting thin film)	5
1	2		
Deposit M1 (lower Nb wiring)		5	6
2	3	R1 (Au resistors)	
PM (alignment marks)			
3	4	6	7
Pattern and Etch M1 (lower Nb wiring)		R2 (PdAu resistors)	

1 Deposit M1 (lower Nb wiring)

- Begin with oxidized Si substrate
- Deposit 120 nm Nb with the Lesker SNS tool
- Instructions for tool use: OneNote/a4/fab/SNS
- Recipe: Nb_wire.js.rcp
- Rate: 80 nm/min; check log book for latest rate
- Insert picture of log book entry

2 PM (alignment marks)

- Spin: SPR600 @ 3000 rpm
- Expose: 220 mJ/cm²
- Develop: double puddle, 30 s, 30 s
- Run through spin rinse dry
- Inspect with microscope
- Etch with Oxford fluorine ICP RIE
 - Recipe: Nb PM He
 - * SF₆: 30 sccm
 - * RF: 25 W
 - * ICP: 800 W
 - * Pressure: 15 mTorr
 - * He: 5 Torr
 - Etch: 70 s
 - Typical DC bias: 60 V @ 25 W RF
 - No endpoint monitoring
- Ash: 2 min

3 Pattern and Etch M1 (lower Nb wiring)




Figure 1: Typical endpoint signal of Nb etch. The small peak after the dip is interpreted as the end of the etch. Endpoint is called 10 s-20 s after that.

- Spin: SPR600 @ 3000 rpm
- Expose: 220 mJ/cm²
- Develop: double puddle, 30 s, 30 s
- Run through spin rinse dry
- Inspect with microscope
- Etch with PlasmaTherm
 - Recipe: 150mm_Nb_sloped_ManEP
 - * SF₆: 40 sccm
 - * O₂: 16 sccm
 - * RF: cut after strikie
 - * ICP: 500 W
 - * Pressure: 6.5 mTorr
 - * He: 4 Torr
 - * Rate: ~0.51 nm/s; ~31 nm/min
 - * Note: Selectivity over resist is poor; limit to 300 nm Nb to be etched
 - Etch: ~230 s
 - No DC bias
 - Use endpoint; typical signal shown in Fig. 1
 - Insert picture of endpoint signal and log book entry
- Ash: 2 min
- Clean: acetone dirty 2 min, acetone clean 2 min, IPA, spin rinse dry
- Inspect with microscope
- Measure thickness with profilometer

4 STF (superconducting thin film)




Figure 2: Typical endpoint signal of MoSi etch. The small peak after the dip is interpreted as the end of the etch. Overetch by 10 s-20 s after that peak.

- Ash 5 min
- Deposit MoSi in AJA

- Recipe: MoSi - jms
 - RF plasma clean for 150 s at 80 W
 - Typical DC voltage: 100 V
 - Deposit MoSi: 50 s
 - Voltage: 460 V
 - Current: 440 mA
 - Deposit a-Si: 66 s
 - Voltage: 183 V
- Pattern
 - Spin: SPR600 @ 3000 rpm
 - Expose: 220 mJ/cm²
 - Develop: double puddle, 30 s, 30 s
 - Run through spin rinse dry
 - Inspect with microscope
 - Etch with Oxford FI
 - * Recipe: opto-WSi-v2-lowHeForCarrier
 - SF₆: 1 sccm
 - Ar: 80 sccm
 - RF: strike at 30 W, cut to 10 W as quickly as possible
 - ICP: 600 W
 - Pressure: 10 mTorr
 - He: 5 Torr
 - Rate: ~8 nm/min
 - * Etch: ~60 s-70 s
 - * DC bias: 67 V
 - * Use endpoint; typical signal shown in Fig. ??
 - * Insert picture of endpoint signal and log book entry
 - Ash: 2 min
 - Clean: acetone dirty 2 min, acetone clean 2 min, IPA, spin rinse dry
 - Inspect with microscope

5 R1 (Au resistors)

- Pattern for liftoff
 - Ash: 3 min
 - Spin: LOR3A @ 2000 rpm
 - Clean wafer backside if necessary with EBR
 - Bake: 150°C for 5 min
 - Spin: SPR660 @ 3000 rpm, no P20 (recipe: OPTO/3IN-SPR660-NO-3000-LOR IDI)
 - Expose: 220 mJ/cm²
 - Bake: 110°C
 - Develop: double puddle, 30 s, 30 s
 - Run through spin rinse dry
 - Inspect with microscope
- Deposit Au in Lesker Lab18
 - Load wafer in load lock
 - Pump down
 - Run Plasma clean from vacuum fast
 - Record DC voltage in log book (typical: 245 V)
 - Plasma clean runs in load lock
 - Transfer wafer to process chamber
 - Deposit: 4 nm Ti
 - Typical dep params: 0.2 nm/s; 78 mA
 - Deposit: 120 nm Au
 - Typical dep params: 1 nm/s; 58 mA
 - Deposit: 4 nm Ti
 - Transfer wafer to load lock
 - Vent load lock
 - Insert picture of log book entry
- Perform liftoff
 - Begin heating NMP (PG remover) to 150°C
 - Soak in acetone as long as possible
 - Transfer wafer to dirty acetone beaker
 - Sonicate in dirty for 5 min
 - Exchange acetone
 - Sonicate in dirty for 5 min
 - Exchange acetone
 - If all material is visibly lifted off, move to clean acetone beaker
 - If not, repeat until removed, but at least 10 min sonics in dirty acetone with acetone exchange at 5 min
 - Sonicate in clean for 5 min
 - Spray wafer with acetone spray bottle into sink
 - Place wafer in hot NMP
 - Soak wafer in hot NMP for 20 min
 - Spray wafer with IPA into sink
 - Rinse wafer in beaker with IPA
 - Run through spin rinse dry

6 R2 (PdAu resistors)

- Pattern for liftoff
 - Ash: 3 min
 - Spin: LOR3A @ 2000 rpm
 - Clean wafer backside if necessary with EBR
 - Bake: 150°C for 5 min
 - Spin: SPR660 @ 3000 rpm, no P20 (recipe: OPTO/3IN-SPR660-NO-3000-LOR IDI)
 - Expose: 220 mJ/cm²
 - Bake: 110°C
 - Develop: double puddle, 30 s, 30 s
 - Run through spin rinse dry
 - Inspect with microscope
- Deposit PdAu in Lesker Lab18
 - Load wafer in load lock
 - Pump down
 - Run Plasma clean from vacuum fast
 - Record DC voltage in log book (typical: 245 V)
 - Plasma clean runs in load lock
 - Transfer wafer to process chamber
 - Deposit: 4 nm Ti
 - Typical dep params: 0.2 nm/s; 78 mA
 - Deposit: 135 nm PdAu
 - Typical dep params: 1 nm/s; 79 mA
 - Deposit: 4 nm Ti
 - Transfer wafer to load lock
 - Vent load lock
 - Insert picture of log book entry
- Perform liftoff
 - Begin heating NMP (PG remover) to 150°C
 - Soak in acetone as long as possible
 - Transfer wafer to dirty acetone beaker
 - Sonicate in dirty for 5 min
 - Exchange acetone
 - Sonicate in dirty for 5 min
 - Exchange acetone
 - If all material is visibly lifted off, move to clean acetone beaker
 - If not, repeat until removed, but at least 10 min sonics in dirty acetone with acetone exchange at 5 min
 - Sonicate in clean for 5 min
 - Spray wafer with acetone spray bottle into sink
 - Place wafer in hot NMP
 - Soak wafer in hot NMP for 20 min
 - Spray wafer with IPA into sink
 - Rinse wafer in beaker with IPA
 - Run through spin rinse dry